

T-Connector Wiring Kit

INSTALLATION INSTRUCTIONS

Fits: 2006-07 Chevrolet HHR

Kit Includes:
(1) Wiring Harness
with 4-Flat Connector
(1) 6" Cable Tie
(1) #10 Self Tapping Screw

© 2004 Electrical Products Co.

T-Connector Wiring Kit

INSTALLATION INSTRUCTIONS

1. Read instructions thoroughly before beginning.

2. Open the rear hatch and locate both of the wiring access side panels located in the cargo area of the vehicle. Carefully remove the foam insulation liner from each side to access the mating connectors. **Note** (There are two sets of taillight connectors use the top set of connectors to mate with the T-Connector)

3. Beginning on the drivers side, unplug the taillight connectors, while being careful not to break the locking tabs. Inspect the connectors for dirt & debris and clean if necessary. Plug the T-Connector ends containing the **Yellow** wire into the vehicle harness connectors until they lock into place. Take care not to damage the locking tabs.

4. Locate an appropriate position on the vehicle frame to attach the White wire containing the ground ring. Drill a 3/32" hole and attach the T-Connectors White wire with the ring terminal to the vehicle using the #10 screw provided.

Caution: Do not drill into any exposed surfaces or through the vehicle body.

5. Pull up the cargo floor panel, and remove the cargo tray by unscrewing the spare tire retaining nut. Remove the cargo tray and set aside. Route the T-Connector containing the **green** wire behind and under the trim panel, along the vehicle floor near the spare tire to behind the trim panel to the wiring connector access area.

6. Repeat step 3 for the passenger side, using the T-Connector containing the Green wire.

Caution: Make sure to avoid areas that could cut, pinch or burn the wires when routing the harness across the vehicle.

7. Confirm correct operation with a test light or by using a trailer.

8. Replace the foam insulation liners and wiring access panels, cargo tray, spare tire retaining nut & cargo floor panel removed during installation.

9. Store 4 flat connector in rear cargo area when not in use.