

55529

KIA SPORTAGE

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



1. Locate the vehicle tow plug. It will be located on the passenger side between the bumper and the rear tire. Remove the protective cap making sure not to damage the locking tabs. **A B**

2. Connect the harness end to the vehicle's connector. Be sure that the connector is fully inserted with locking tabs in place.

3. Route the 4-flat wire to the bumper. Then route the wire along the bumper to the center of the vehicle.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



55529