

T-Connector Wiring Kit

INSTALLATION INSTRUCTIONS

1. Read instructions thoroughly before beginning.
 2. Locate vehicle wiring harness underneath the rear of the vehicle along the frame rail. There will be connectors on the factory wire harness similar to those on the T-Connector.
 3. Separate the vehicle connectors being careful not to damage the locking tabs. Check for any dust, dirt or debris and remove if necessary.
 4. Plug the T-Connector into the vehicle harness connector and press firmly together until the locking tabs engage.
 5. Locate an appropriate position on the vehicle frame to attach the grounding screw. Clean away any dirt, debris or undercoating and drill a 3/32" hole.
- Caution: Do not drill into any exposed surfaces or through the vehicle body.**
6. Attach the T-Connectors white wire with the ring terminal to the vehicle using the #10 screw provided.
 7. Route the 4-flat connector to the center of the bumper and secure with the tie straps provided.
 8. Confirm correct operation with a test light or by using a trailer.



#55551

T-Connector Wiring Kit INSTALLATION INSTRUCTIONS

Fits: 2004 Ford F-150 Pickup (New Body Style)

Looking for dependable trailer hitches and towing? Rely on CURT for quality and long-lasting products.