

55560

CHEVY EQUINOX
PONTIAC TORRENT

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the rear tailgate and locate the vehicle jack storage compartment on the drivers side. [A] Remove panel and tire jack to access harness area. [B]
2. Locate the tow vehicle's trailer harness connector. This harness is located in the inside of the driver's side tire jack compartment. [C]
3. Locate the 6-pin connector, which is taped to the vehicle wiring harness. This is located at the floor of the vehicle jack compartment. [D]
4. Remove the tape on the vehicle's plug and insert the T-connector into the vehicle's trailer plug harness. Be sure that the T-connector is fully inserted with the locking tabs in place.
5. Locate a suitable grounding point near the connector such as the vehicle's frame or cross member. Clean dirt and rustproofing away from area. Drill 3/32" hole and secure white wire using eyelet and screw provided.

WARNING!
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage to vehicle and/or personal injury.





55560