

T-Connector Wiring Kit **INSTALLATION INSTRUCTIONS**

Fits: 2007 Chevy Equinox
2007 Pontiac Torrent
2007 Suzuki XL7

Kit Includes:
(1) Wiring Harness
with 4-Flat Connector
(3) 10 Amp Mini Fuse
(2) Micro Relay

© 2004 Electrical Products Co.

T-Connector Wiring Kit **INSTALLATION INSTRUCTIONS**

1. Read instructions thoroughly before beginning.

2. Open the rear hatch and remove tire jack access panel and the tire jack, locate the tow/trailer connector at the bottom of the tire jack compartment by pulling up the felt insulation. Plug the Trailer harness into the tow/trailer connector. Make sure that both connector faces are free of dirt and debris. Seat connectors until the locking tabs are in place.

2A. (Suzuki XL7) Open the rear hatch and remove tire jack access panel and the tire jack, locate the tow/trailer connector behind the trim panel by reaching up and rearward while facing the tire jack compartment. Plug the Trailer harness into the tow/trailer connector. Make sure that both connector faces are free of dirt and debris. Seat connectors until the locking tabs are in place. Note: The T-Connector end will only plug in one way because of the connector key positions to ensure proper operation of the 4-Flat.

3. Open the hood of the vehicle and locate the fuse and relay box. Open the fuse and relay box while being careful not to damage the locking tabs on the cover "screwdriver may be required for removal". Refer to the fuse and relay box cover for diagram for fuse and relay placement. (35 PRK LAMP / TRLR 10A), (37 LT TRLR STOP/TRN 10A), (43 RT TRLR STOP/TRN 10A), (58 RT TRLR STOP/TRN RLY), (59 LT TRLR STOP/TRN RLY).

4. Confirm correct operation with a test light or by using a trailer.

5. Replace fuse and relay box cover and tire jack to their original positions. Store 4-flat connector in tire jack compartment when not in use. Replace tire jack compartment cover.