

## ***T-Connector* Wiring Kit**

### **INSTALLATION INSTRUCTIONS**

Fits: 2005-06 Ford F-150

Kit Includes:  
(1) Wiring Harness  
with 4-Flat Connector  
(2) 6" Cable Tie

## **T-Connector Wiring Kit**

### **INSTALLATION INSTRUCTIONS**

- 1. Read instructions thoroughly before beginning.**
- 2.** Locate vehicle taillight wiring harness. This harness will have the same connector end as the T-Connector. The most common location is 6" behind the rear bumper near the center of the vehicle.
- 3.** Remove protective cap (not required on all installations) from the vehicle taillight wiring harness. Connectors will disconnect by pressing or lifting on a locking tab and pulling apart. Inspect the connectors for dirt and debris and clean if necessary.
- 4.** Plug T-Connector into mating vehicle connectors. Be sure connectors are fully inserted with the locking tabs in place.
- 5.** Confirm correct operation of the T-Connector with either a test light or by using a trailer.
- 6.** A heavy duty flasher may be required to eliminate rapid flashing.