

56039

MITSUBISHI ENDEAVOR

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the rear hatch and remove vehicle floor coverings and spare tire storage cover. [A] Remove storage compartment cover on drivers side by removing two cargo anchor brackets using a 10 mm socket. [B]

2. Under the storage compartment locate the vehicles factory tow harness. [C] Insert the harness into the vehicles tow harness. Make sure the connectors are fully inserted with locking tabs in place. [D]

3. Adhere the black converter box to the frame of the car using the double-sided tape provided. [E] Secure any loose parts of the T-connector with the cable ties provided.

4. Route the 4-flat through the grommet in the rear center of spare tire storage area. Slit the grommet and seal the grommet with silicone to make a moisture tight seal. [F] Outside the vehicle route the 4-flat to the center of the bumper and secure in a convenient out of the way location using the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

