

56047

BUICK LUCERNE

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and remove the vehicles rear scuff panel by removing the plastic fasteners. **A** **B** Starting on the drivers side pull back on the vehicles trunk liner to expose the vehicles taillight wiring harness. It will have connectors matching those on the T-connector. **C**

2. Separate the connectors and insert the T-connector end with the yellow wire in-between the separated connectors making sure that the locking tabs are in place.

3. Route the T-connector end with the green wire under the removed scuff panel and behind the partially removed felt trunk liner on the passenger side. Repeat step 2 on the passenger's side using the green wire.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.

6. Replace any parts during installation.

WARNING!
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

