

56058

KIA AMANTI

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



1. Open trunk and remove threshold panel. Partially remove the felt trunk liner on driver's side, exposing the taillight wiring. **A** **B**
2. Separate the harness connectors, being careful not to break the locking tabs.
3. Insert the T-connector between the harness connectors and lock into place. (Note: the single plug-in for the right turn function is on the driver's side). Be sure that the connectors are fully inserted with locking tabs in place.
4. On the driver's side, locate existing ground stud. Loosen bolt, place screw eyelet on stud and re-tighten bolt. Make sure all other ground connections are secure when removing and reattaching the ground stud.
5. Secure the black converter box and trailer wiring with double sided tape, cable ties and/or locate a suitable mounting position and drill a 3/32" hole and secure with screw provided using mounting tab on converter to prevent damage or rattling.
6. Reposition the trunk liner and reattach the threshold panel.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surfaces before drilling to avoid damage to vehicle and/or personal injury¹

