

56062

SCION XB

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



1. Open rear hatch and temporarily remove the rear floor covering and foam tire cover. **[A]**

2. Remove the hard plastic panels on each side of the spare tire storage by removing the 2 nuts with a 10mm socket. **[C][B]**

3. Remove the rear interior trim panels on both the driver and passenger side of the vehicle. **[D]**

4. On the driver and passenger sides of the vehicle locate the vehicle's taillight wiring harness located behind the panels just removed. The taillight wiring harness will have a connection point on both sides matching the ends of the T-Connector. Separate these connectors being careful not to break the locking tabs. **[E]**

5. On the driver's side place the black converter box just below the side trim panel and route the end with the yellow wire behind the panel. Insert the T end between the vehicle wiring connectors and lock into place. Be sure the locking tabs are fully inserted without damaging them. **[F][G]**

6. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

7. Route the T-Connector end with green wire to the passenger's side along the threshold and up behind the panel. Insert the T end between the vehicle wiring connectors and lock into place. Be sure the locking tabs are fully inserted without damaging them.

8. Secure and loose parts of the T-connector with the cable ties provided.

9. Route the black power wire from the battery as shown on the CME-PCL-INS sheet included. Route the black wire through the rubber grommet in the tire storage area to the black converter. **[H]**

10. Reinstall the plastic trim panels, threshold, storage covers, floor covering and other items that may have been removed during installation.

NOTE

Store 4-Flat connector in rear cargo area when not in use. **[I]**

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage vehicle and/or personal injury.



56062

Looking for dependable trailer hitches and towing? Rely on CURT for quality and long-lasting products.