

56076

PONTIAC GRAND PRIX

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and remove the vehicle's floor covering (A). Remove the rear scuff panel by removing the plastic fasteners holding it in place (B). On each side of the trunk pull back the felt trunk liner behind the taillight (C). Behind the trunk liner remove three plastic wing nuts holding the taillight in place (D). Pull out on the taillights to remove. Locate the vehicle's taillight wiring harness connectors (E). The connectors will be similar to those on the T-Connector harness.

2. Starting on the driver side of the vehicle separate the connectors taking care not to damage the locking tabs (F). Insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

4. Route the T-Connector with the green wire and the 4-flat down through the opening under the taillight. Under the vehicle route the T-Connector end with the green wire across the backside of the bumper to the passenger side and up through the opening under the passenger side taillight. Repeat Step 2 on the passenger side using the green wire.

5. Secure the 4-flat to the center of the vehicle in a convenient out of the way location. Secure any loose wires with the cable ties provided.

6. Secure any loose parts of the T-Connector with the cable ties provided.

7. Reinstall all items removed during install.

