

56083

LEXUS RX 350
LEXUS RX 450H

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Locate the vehicles factory tow harness under the vehicle on the drivers side frame rail location (S5). **[A]**

2. Remove the protective cap and save. **[B]** Insert the harness connector into vehicles harness connector make sure the connector is fully inserted with locking tabs in place. **[C]**

3. Route the 4-flat to the center of the vehicle along the backside of the bumper and secure in a convenient out of the way location. **[D]** Secure any loose wires with the cable ties provided.

4. Some models may need to be programmed to accept wiring harness. This must be done by a dealer.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

