



Porsche 981 Ducktail Installation Instructions



1. Raise factory spoiler with button located on console.



2. Once raised – Remove screws with T15 Torx Tool, along the front edge and remove spoiler cover.



3. Once top cover is removed, remove the 2 nuts holding the bottom base cover. Remove cover, save the 2 nuts to attach wing brackets with.



4. If the height of the spoiler need to be adjusted, these are the Nuts that can be adjusted to correct the height.



5. Wing will come with Brackets attached with Bolts, Remove brackets from Wing) Install brackets as shown with factory nut removed from before, do not over tighten, leave the brackets loose enough to be able to adjust wing once lowered into position. Will need 2 people to do this step.

6. Install ducktail onto brackets with the 4 bolts that where provided with the wing. Once wing is tightened, have one person lower the wing slowly using the button from the console while you adjust the wing from left to right, and check Gap against Lid. Once Wing is centered, raise wing back up and carefully remove wing, without moving bracket location. Tighten the nuts from Step 5. If the height needs to be adjusted, refer to step 4. Install Wing onto Brackets again, check fit. DONE!

