INSTALLATION INSTRUCTIONS

FOR: Bumper Cover Protectors (all models)



INSTALLATION PACKAGE INCLUDES:

- A) Alcohol Wipes
- B) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **LOCATION**:

See Diagram below.

2. CLEAN & PREP:

For proper installation of Bumper Cover Protector, clean the surface where the Bumper Cover Protector is to be installed using car wash soap and water. Next, using the alcohol wipes, enclosed, clean the surface where Bumper Cover Protector is to be installed. Wipe off excess residue with a clean cloth. Where cooler temperatures prevail, make sure that the bumper cover molding is at room temperature. The recommended surface of vehicle temperature should be at least 75°F/24°C for proper installation. If the surface is cold, use a heat gun or hair dryer to warm before proceeding with the installation.

3. **INSTALLATION**:

<u>Leaving the red liner on the bottom of the mounting tape</u> of Bumper Cover Protector, place the Bumper Cover Protector onto the bumper **as shown in Diagram A below**. Center left to right. When satisfied with alignment, outline each outer edge and rear area of bumper using a grease pencil or masking tape, **as shown in Diagram B below**.

Remove red liner from mounting tape. <u>DO NOT TOUCH THE EXPOSED ADHESIVE</u> with your fingers as the installation is being done. <u>Lightly tack</u> Bumper Cover Protector back onto the outline marks that you made using a grease pencil or masking tape (*NOTE*: if not satisfied with alignment, re-install). After Bumper Cover Protector has been installed and you are satisfied with the alignment, press firmly into place with a soft cloth.





This is the basic installation for all models. Please note that pictures shown are not necessarily of your particular vehicle.

DAWN BODYSIDE MOLDINGS

CHROME SIDE MOLDINGS