



INSTALLATION PACKAGE INCLUDES:

- A) 2 – M6 x 3/8" Screws
- B) 2 – Lock Washers
- C) 2 – Flat Washers
- D) 2 – Paper Hole Locators
- E) 2 – 3/4" Plugs
- F) Instruction Sheet

EXTRA TOOLS NEEDED:

- 1. 1/8" Drill Bit
- 2. Uni-Bit
- 3. Grease Pencil

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **Remove trunk liner.** Leaving the paper liner on the bottom of the mounting feet, measure 8 1/4" from the tip of the trunk lid to the tip of the Sportwing® (**See Diagram A**). Repeat procedure on passenger side. Outline both mounting feet using a grease pencil.
2. Next, set Sportwing® aside onto a soft surface to prevent scratching. Place 2 paper hole locators over 2 mounting holes located on the Sportwing® as shown in **Diagram B**. Place Sportwing® back into outlined marks made in Step #1. Tape down hole locators so that they will stick onto the deck lid and not the Sportwing®. Lift the Sportwing® off of the deck lid and set aside, leaving the hole locators onto the deck lid.
3. Drill into the two holes inside of the paper hole locators with a 1/8" Drill Bit. Continue to drill through second panel. Once drilled, remove hole locators and open holes on top of the deck lid to 7/16" with a Uni-Bit. Proceed to open the trunk and open holes through the second panel to 3/4" using a Uni-Bit.
4. Remove paper liner off of the feet of the Sportwing® and place back into outlined marks made in Step #1.
5. While holding onto Sportwing®, open deck lid and screw in the 2 M6 x 3/8" screws with lock washer and washer attached to mount Sportwing®. After screws have been fastened, place 3/4" plugs provided over holes made through second panel.
5. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A



DIAGRAM B

