



## INSTALLATION INSTRUCTIONS

PART NUMBER: CH-RT11

FOR: 2011 + Dodge Charger

### INSTALLATION PACKAGE INCLUDES:

- A) 4 . M6 x 5/8+Mounting Screws
- B) 4 . Lock Washers
- C) 4 . Flat Washers
- D) 1 . DriversqSide Template . Flip template over for passenger side
- E) Adhesive Pads (for unpainted DAWN )
- F) Instruction Sheet

### EXTRA TOOLS NEEDED:

- 1. 1/8+Drill Bit
- 2. Uni-Bit

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **Remove trunk liner.** Leaving the paper liner on the bottom of the mounting feet, measure 17 3/4" from the tip of the trunk lid back toward the front . most area of the mounting feet, along the driver's side. **See Diagram below.** Repeat procedure on passenger side. Next, center the DAWN left to right on deck lid. Outline both mounting feet using a grease pencil.
2. Set the DAWN aside and position the driversqside template, provided, on the driversqside outline made in Step #1. Flip template over for passenger side. Using a 1/8+or similar drill bit, drill down through the exact center of the spots indicated on the template for your mounting holes through the top panel of the deck lid. Next, using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open the 1/8+ pilot holes that you made in the top panel of the deck lid to 3/8+.
3. Apply Zinc Chromate or touch-up paint on the edges of the four (4) 3/8+holes that you drilled in the deck lid.
4. Remove the paper liner from the bottom of the mounting feet and place the DAWN back onto the outline marks made in Step #1. Lightly press into place. Holding onto the DAWN , open the deck lid and check to see that the 3/8+holes in the deck lid align with the threaded sleeves of the mounting feet. If satisfied with alignment, press firmly into place. If holes do not align, reposition the DAWN until satisfied (**NOTE: if holes and threaded sleeves do not align, open 3/8" holes to the next size**).
5. Using mounting screws, provided, with lock and flat washers, install screws into threaded sleeves of mounting feet and partially tighten all four (4) mounting screws. After all four (4) are started, tighten evenly until tight. **DO NOT OVER TIGHTEN.**
5. Clean up any metal shavings, and you are done.

DIAGRAM A

