



**KJ71042BK**

**1987 - 1995 Jeep YJ**

**1997—2006 Jeep TJ / [Unlimited Hood Vent](#)**



## **Introduction**



is your number one source for Made In The USA quality, Comfort Ride™ leveling kits. Now backed with our exclusive *Go Everywhere* © Lifetime Limited Warranty.

To assure your safety and

proper installation of this product, take a moment to read all instructions and Product Safety Information before trying to install your Daystar® product. Current OEM suspension design is complex: meaning safe and proper installation requires understanding OEM service techniques for disassembly and assembly of the components indicated together with the instructions and warnings set out below and in the OEM service manual and your owner's manual. *Daystar® strongly recommends seeking advice from or having this product installed by a professional mechanic who can inspect your suspension, confirm compatibility with your tire and wheel choice and, if needed, reset alignment to optimize your steering and the fea-*

## **Product Safety Information**

Throughout these instructions important safety information is generally preceded by one of three signal words indicating the relative risk of injury. The signal words mean:

**! WARNING** A hazardous situation which, if not avoided, could result in death or serious injury. You can be Killed or Seriously Hurt if you don't follow instructions.

**! CAUTION** A hazardous situation which, if not avoided, could result in minor or moderate injury. You can be moderately HURT and also may suffer property damage if you don't follow instructions.

**NOTICE** Careful attention is required to this instruction or operation but does generally not relate to personal injury. Damage to your product or other property may result if you don't follow instructions.

### **!WARNING**

Familiarize yourself with all vehicle manufactures' and Daystar warnings, instructions and limited warranties before driving your modified suspension vehicle. Also be aware many states / countries have laws governing on-road vehicle heights and modifications. You are responsible for assuring the safety and legality of your vehicle.

## Tools Needed

Quantity	Description
1	Masking tape (low adhesive painters tape)
1	Drill Motor
1	3/16" Drill Bit
1	1 1/4" Hole Saw (for cutting metal)
1	Phillips Head Screw Driver
1	Center punch
1	Hammer
1	Scissors

## Part List Bill of Materials

Quantity	Part Number	Description
1	M56087 - BK	Right Hood Scoop
1	M56095 - BK	Left Hood Scoop
2	M21128 - BK	Bolt Wedge
4	M4-0.7 x 10mm	3/16" Phillips screw
4	M4-0.7 x 25mm	1" Phillips screw
8	M4	Flat Washer
6	1-1/4"	Rubber Grommet

## Installation Instructions

**!Warning: Always work with appropriate personal safety gear including safety glasses, gloves and hearing protection if using air powered tools.**

Begin by inspecting the components & hardware for damage. Then compare components & hardware to the bill of materials for completeness.

1. Clean the install area of the hood, so that all debris that can effect the installation are removed.
2. Disconnect the positive battery cable.  
Notice: To ensure the cable does not make contact with the battery terminal, securely wrap the cable end with a rag.
3. Using the scissors, carefully cut out the template.  
Notice: Special care should be taken with the bottom and rear edges, they will act as the alignment guides in a later step.
4. Starting with the passenger side of the Jeep, place the template on the hood of the Jeep. Take care to ensure the bottom and rear portions of the template line up with the back and bottom of the hood. This step is a crucial part of a perfect install.



5. With the painter's tape affix the template to the Jeep.

Notice: Before any holes are drilled make sure the template is located on the hood correctly.

6. Using a center punch and hammer locate the centers of the four (4) mounting holes and the three (3) vent holes.

Notice: Do not strike the center punch with too much force, or damage to the hood will occur.

7. Use caution when drilling holes. Make sure there is not any items under the hood that will be damaged. It is a good idea to prop the hood up at a workable angle to provide additional under hood clearance during the



drilling steps.

8. Starting with the 3/16" drill bit drill the four (4) mounting holes.


Notice: When drilling the two (2) mounting holes located on the outside curvature of the hood. Start with the drill perpendicular to the hood. Once, the drill is through the hood rotate the drill up 90 degrees



9. Change over to the 1-1/4" hole saw and cut out the three (3) vent holes.



10. Deburr the holes drilled in the steps 8 & 9 and use some touch up paint on bear metal edges to prevent corrosion.
11. Once the paint is dry install the supplied grommets into each of the three (3) vent holes.




12. Open the hood and rest it on the factory hood prop.
13. Locate the following components: 4 x flat washers, 2 x 3/16" long bolts, 2 x 1" long bolts, 1 x Extractor Hood Vent, 1x bolt wedge.
14. Place a flat washer on each bolt



15. Starting with the 3/16" long bolts, secure the Daystar hood vent to the hood.

Notice: Leave the bolts loose, so there is some play in hood vent  
This will make locating the remaining mounting bolts easier.



16. Move onto the 1" long bolts along with the bolt wedge. Match the curved side of the bolt wedge to the curve of the hood. It may be necessary to wiggle the Hood Vent in order to align all of the mount-
17. Once all four (4) of the mounting bolts are located, tighten them.



**Congratulations! You have just completed the install, take a step back and admire your new functional hood vents from Daystar.**



### **Daystar® Lifetime GoEverywhere Limited Warranty**

Your Daystar® Comfort Ride or Budget Boost leveling kit is covered by the following **Go Everywhere Lifetime Limited Warranty** provided exclusively by Daystar Products International, Inc..

**What is Covered? Real Life Use, Off Road & On:** Subject to the terms, exclusions and limitations herein, Daystar® warrants to the initial retail purchaser that your Comfort Ride™ or Budget Boost™ leveling kit shall be free of defects in material and workmanship for so long as it is properly installed on a single vehicle owned by the initial retail Daystar® purchaser.

### **What is Not Covered? Your Vehicle & Parts Not Daystar's GoEverywhere:**

Your Daystar **Limited Warranty** does not cover: (a.) damage to your vehicle, vehicle systems (ex. electronic stability control) other products, components or property not manufactured by Daystar to our exclusive *GoEverywhere* standards, (b.) customer choice of vehicle configuration/tire and wheel combinations contrary to Daystar® recommendations, warnings or applicable laws, (C.) Acts of God, weather, corrosion, accidents, theft, vandalism, negligent misuse or intentional damage, other exclusions under your OEM Limited Warranty.

**Remedy Limited to Repair/Replacement. Get back on your favorite trail fast.** The exclusive remedy provided hereunder shall, upon Daystar's inspection and option, be either repair or replacement of the Comfort Ride™ or Budget Boost™ leveling kit or parts covered under this **Limited Warranty**. All labor, removal, shipping and installation costs are customer's responsibility.

### **Other Exclusions –Limitation of Damages - Your Rights Under State Law. Stuff Lawyers Say.**

At Daystar® we aren't big fans of lawyers, even ours. Still, he says our **Limited Warranty** has to include this stuff. In consideration of the purchase price paid, neither Daystar® nor any independent Daystar® distributor or repair person are responsible for any time loss, loss of vehicle use, rental costs, transportation, labor or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. No Daystar® employee or independent distributor is authorized to make any statement or representation altering the terms of Daystar's *GoEverywhere Lifetime Limited Warranty*. **Your exclusive remedy hereunder for covered parts is repair/replacement as described above.** This **Limited Warranty** gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability, fitness for a particular purpose or other implied warranty are limited to a period of four (4) years from date of initial retail purchase. Daystar® reserves the rights to: (a.) require invoice or other proof of purchase; (b.) make future revisions to these products and **Limited Warranty** without prior notice or obligation to upgrade your Daystar® product.

© Daystar Products International, Inc., 9.15.13. All rights reserved.

**DAYSTAR**  
Truck and Jeep Accessories

**CARRY MORE WITH CAM CANS**  
SAFE & SECURE FLUID & GEAR STORAGE

**NEW**

**Cam Can Trail Box**  
 KU711140R Cam Can Trail Box (Trail Box Only)  
 KJ710350R Cam Can Trail Box (Jeep Complete Kit)  
 KT710010R Cam Can Trail Box (Toyota Complete Kit)

**Cam Can Universal Mounting Kit**  
 KU71118 Mount your Cam Can on the garage wall, trailer or any other flat surface.

**Double Cam Can Mount**  
 KU71116 Double-mount kit available. Includes a longer center shaft and allows you to stack two Cam Cans together on the mounting plate.

**A. Cam Can Drinking Water**  
 KU71114RB (Cam Can Only)  
 KJ71035RB (Jeep Complete Kit)  
 KT71001RB (Toyota Complete Kit)

**B. Cam Can Fluids (Non-Fuel)**  
 KU71114GN (Cam Can Only)  
 KJ71035GN (Jeep Complete Kit)  
 KT71001GN (Toyota Complete Kit)

**ASEASY AS...**

**AIR BAG CRADLE**  
 MADE FROM EXTREMELY TOUGH DAYSTAR PTMEG POLYURETHANE **KU09140BK**

Get all the benefits of an air bag cradle whether you are towing a heavy load or not

**GO EVERYWHERE**



ESTABLISHED IN 1977

