



KT09116

Toyota Tacoma 05-08 / 4-Runner 03-08
Easy install front
4wd & 2wd 6 lug only



Installation Steps

1. Read all instructions and check bill of materials and tools before beginning.
2. Disconnect the negative battery cable.
3. Place the vehicle on a clean and level surface. Set the parking brake and place wheel chocks behind the rear wheels. Jack up the front of the vehicle by the frame with a floor jack and support vehicle at the frame rails with approved jack stands. **NEVER WORK UNDER AN UNSUPPORTED VEHICLE.**
4. Disconnect the ABS and brake lines from the upper a-arm and spindle (10mm and 12mm bolts.



5. Disconnect the sway bar on both side at the spindle. (17mm bolt.)



6. Remove the upper strut nuts.(14mm nuts) You will need to reuse them later.
7. Remove upper ball joint nut (19mm nut) and separate the ball joint from the spindle by hitting the side of the spindle. **DO NOT** use a ball joint separator tool it can damage the ball joint boot.



Installation Steps

8. Remove the lower strut bolt and nut (19mm) .
9. Remove the strut from the vehicle.
10. Install the stud extenders and spacer on the top of the strut plate.



11. Reinstall the strut into the vehicle and tighten the upper strut nuts. You will have to push up on the upper a-arm to get the strut back in.
12. Reinstall the suspension working in reverse order.



13. Recheck all bolts after 500 miles.
14. Daystar Recommends that you have your wheel alignment checked.

TOOLS NEEDED

1. Floor Jack
2. Jack stands
3. Wheel chocks
4. Set of metric tools from 10mm to 19mm
5. Hammer

Bill of Materials

<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
M03724	Spacer	2
S11057	Stud ext	6
P11131	Instructions	