



DefenderWorx SS Badges, RS Badges & Reverse Lights **Installation Instructions:**

1. IMPORTANT NOTICE - Before starting, make sure the surface area is clean and free from any kind of wax (i.e. Armor-All, Turtle Wax or Autoglym.). The 3M Tape WILL NOT adhere if there are any traces of these substances on the vehicle's exterior.
2. Clean the surface, which you wish to apply the part, using rubbing alcohol or some sort of an adhesive promoter.
3. Peel the red film from part, line it up and adhere to vehicle.
4. Enjoy your new DefenderWorx customer accessory.