



DefenderWorx Cup Holder Trim, Speaker Ring Covers, Trunk Panels & [Door Kick Panel](#) Installation Instructions:

1. IMPORTANT NOTICE - Before starting, make sure the surface area is clean and free from any kind of interior cleaner (i.e. Armor-All, Turtle Wax, Autoglym, etc.). The 3M Tape WILL NOT adhere at all if there are any traces of these substances on the vehicle's interior.
2. Clean the surface that you wish to apply the part to using rubbing alcohol or some sort of an adhesive promoter.
3. Peel the red film from the part, line it up and adhere to vehicle.
4. Enjoy your new DefenderWorx customer accessory.