



H2 HERITAGE SHIFTER INSTALLATION INSTRUCTIONS



Set emergency brake. Partially turn key, depress brakes while shifting gear into drive position. Remove torx-head screw (T15) from original shift lever and insert torx-head screw into the new shift lever. Thread the screw a minimal amount and bring shifter down so that the rectangular section is almost even with the black strip located on the shift console. Make sure the screw sits fully into the small hole in the metal tube. Once shift lever is properly tightened, you should be able to work it by pushing down to change gears.