

H3/H3T FUEL DOOR

Trim template, lay over stock fuel bucket and mark holes top and bottom using sharp object. Remove fuel bucket and drill holes using 7/32 drill bit. Place fuel door assembly face down and screw down the fuel receiver making sure the head of the screws are flush or slightly below. Now replace on the vehicle.

