



PERFORMANCE PRODUCTS

## INSTALLATION INSTRUCTIONS

### Quick Fix Tape / Fire Tape

**KIT CONTENTS:**

Quick Fix Tape / Fire Tape

**TOOLS:**

Scissors

Towel/rag for cleaning

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided.



Figure 1



Figure 2



Figure 3

1. Dry and clean area as best as possible. **Fig. 1**
2. Remove Quick Fix Tape / Fire Tape from package and remove 1" - 2" of plastic backing from tape.
3. Start 1" - 2" before area to repair.
4. Wrap tape over itself, stretching the tape while wrapping with a 2/3rds overlap. **Fig. 2**
5. Continue wrapping over the repair area finishing 1" - 2" beyond repair. **Fig. 3**
6. Wrap tape over itself then cut and firmly press end into tape. **Fig 3**