



INSTALLATION INSTRUCTIONS

Boom Mat Black UnderHood Thermal Acoustic Lining

KIT CONTENTS:

#050129 - 32" x 59" (13.1 sq.ft.) Under Hood Thermal Acoustic Lining

NOTES:

It is not required to clean the area that the Boom Mat is being installed. However, the cleaner the area the stronger the bond will be. Use a wax and grease remover and/or isopropyl alcohol.

TOOLS:

Scissors or snips, Cardboard/Poster board to use as a template

SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.

INSTRUCTIONS:

1. Making a template will aid in proper and professional installation.
2. Trim Under Hood to desired size using a sharp scissors or snips.
3. Remove the backing to expose the adhesive and carefully apply to clean and dry desired area.
4. After Under Hood is set in proper location, apply pressure to ensure a strong bond with installation surface.

