



**NOTE: TEMPLATES ARE IDENTICAL**

1. Cut template along outline and place template inside of the housing.
2. Align line to center with the socket hole in housing.
3. Mark the hole centers and drill using a 5/32" size drill bit.
4. Use same template for both housings.