



1. Cut out the appropriate templates, position them on the inside of the housing buckets aligning the **RED** line centered with the socket hole.

2. Drill 5/32 holes and test fit the [LED panel](#) assembly before final mounting. Use the same template for all housing buckets.

● Drill the **BLUE** markings when mounting LED panels with Reverse LED's PN 1100170R.

● Drill the **ORANGE** markings when mounting LED panels PN 1100171.