


1. Cut out the template and position it on the inside of the housing, matching the light socket location.

2. Drill  marks 5/32" and test fit the LED panel before final mounting. Use the template for both housings.