




1. Cut out the templates and position them on the front side of the corresponding lens. The arrow should point towards the edge of the lens.

2. Drill  marks 5/32" and test fit the LED panel before final mounting.

NOTE: TEMPLATES ARE NOT IDENTICAL

