



DINAN

**FRONT STRUT INSERT
INSTALLATION NOTES**

PART NUMBER DI40-1364

APPLICATION: 1995-99 M3
1998-02 M-Roadster, M-Coupe

Congratulations for being selective enough to use a Dinan Engineering shock absorber. We have spent many hours developing our suspension components to assure that you will receive maximum performance and durability with minimum difficulty in installation.

PLEASE READ BEFORE BEGINNING INSTALLATION

These inserts were designed to be installed into unmodified stock strut housings. If your strut housings have previously been modified to accept a Koni strut insert, please pay particular attention to the housing length shown in Koni's modification instructions (included in this box). Further modification of your already-modified strut housing may be required!

DO NOT WORK ON VEHICLES SUPPORTED BY A JACK ONLY. USE SECURE JACK STANDS!

If your strut housings are stock:

- Modify the strut housing and install per the included Koni instructions.

If you are replacing a Koni insert:

- Remove old insert.
- Measure length of strut housing and compare to length indicated on Koni's instructions.
- Modify length of strut housing if required.
- Install new insert.