



D180-0007A Carbon Fiber Strut Brace

INSTALLATION INSTRUCTIONS

Thank you for purchasing a Dinan product. Some mechanical skill is required to install this kit. If you feel you don't have the requisite skill or tools, please arrange for a qualified repair facility to perform the procedure. We recommend that you read these instructions completely before proceeding so that you're familiar with all the steps before the actual installation.

Parts List

- 1 – D183-0012 Carbon Brace
- 2 – M8 X 25 mm Socket Head Cap Screw
- 2 – M8 X 30 mm Socket Head Cap Screw
- 2 – 8mm Flat Washers
- 2 – 8mm Fender Washers
- 1 – Cable Clip

Installation Instructions

- Remove coverings per TIS 64 31 061 & 64 31 010.
- Remove stock Brace.
- Install Dinan Brace. The short bolts and small washers are used in the rear, and the long bolts and large washers are in the front.
- Torque bolts to 24NM (17.7 ft-lbs).
- Insert the supplied clip into the hole under the Dinan Brace, and use it to secure any loose wiring nearby.
- The hole on top of the Dinan Brace is used to attach the positive battery terminal for 535i vehicles.

Happy Motoring!