



FREEFLOW EXHAUST SYSTEM INSTALLATION INSTRUCTIONS

Part Number: D660-4604

Applications: 2001-05 M3

PARTS LIST

1	Freeflow Exhaust Assembly
1	Installation Hardware Pack

Please Note:

- Thank you for purchasing a Dinan High Performance Muffler! Some mechanical skill is required to install this muffler. If you are not familiar with this procedure, we strongly recommend that you arrange for a qualified BMW repair facility to perform this installation.
- Do not work on vehicles supported by a jack only. Use secure jack stands!
- For best results, we recommend that this muffler be used with the appropriate Dinan software for your vehicle. Please contact your Dinan representative for details.

INSTALLATION:

1. Remove the stock muffler following recommended BMW procedure.
2. The installation of the Dinan muffler is simply the reverse of removal. Please take note to:
 - Examine the rubber mounts for damage. Replace as necessary.
 - Examine the exhaust gaskets for damage. Replace as necessary.
 - Attach the Dinan muffler to the exhaust pipes using the bolts and locknuts supplied in the kit. Do not reuse the stock hardware at this connection.
 - The hangers are slotted to allow some adjustability. Be sure to center the exhaust tips in the openings in the rear bumper, with least 1/2" of clearance above the exhaust tips to the rear bumper. Also verify that both sets of exhaust tips are level.

NOTE: Upon initial startup after muffler installation, the exhaust may sound strange. This is a normal occurrence, as the internal muffler packing has not settled into position. Perform moderate driving for several miles to remedy this situation.