

DIODE DYNAMICS

PERFORMANCE LIGHTING TECHNOLOGY

2015+ Ford Mustang Sidemarker (EU/AU) Installation Guide



1. To begin, unclip one of the the license plate light housings from the rear bumper. Using the included T-taps, clamp one T-tap onto each license plate wire. Next, plug the pink connectors on the wiring harness into each T-tap. After that, run the two black connectors from the harness through the license plate light hole. When routing the black connectors, be sure to push them downwards towards the ground. Run the two black connectors on the harness to the sidemarker location on each side of the vehicle.



2. Next, remove the factory sidemarker by reaching behind and depressing the tab on the side closest to the wheel well. Once the tab is unclipped, slide the sidemarker towards the wheel well to pull the sidemarker housing out. Set the factory sidemarker aside. It will not be reused. Plug the LED sidemarker into the wiring harness.



3. Insert the socket into your new sidemarker housing. Be sure to push the connector all the way into the housing.



4. Finish your installation by sliding and clipping your new LED sidemarker into place. Be sure to tuck all wiring away from any heat element, including the exhaust.