

# DIODE DYNAMICS

PERFORMANCE LIGHTING TECHNOLOGY

## 2015+ Ford Mustang Sidemarker Installation Guide



Thank you for your purchase of this unique product for your Ford Mustang! With this plug-and-play LED Sidemarker, you will be able to upgrade your factory sidemarker to a brighter, more modern appearance on the road. This product is a direct replacement for your factory sidemarker.



1. Remove the factory sidemarker by reaching behind and depressing the tab on the side closest to the wheel well. Once the tab is unclipped, slide the sidemarker towards the wheel well to pull the sidemarker housing out.



2. Looking at the factory sidemarker housing, rotate the socket clockwise and pull the socket out. Set the factory sidemarker aside. It will not be reused.

## 2015+ Ford Mustang Sidemarker Installation Guide



3. Allow the factory bulb to cool and remove the factory bulb. Insert the connector on your LED sidemarker in its place.



4. Reinstall the socket back into your new sidemarker housing by turning the socket counter-clockwise to lock it into place.



5. Finish your installation by sliding and clipping your new LED sidemarker into place