

2016-17 TOYOTA TACOMA, 3.5L  
(OFF-ROAD "RACE" USE ONLY)



### **LEGALITY NOTES**

These downpipes **DO NOT** comply with California Air Resource Board regulations and are **NOT LEGAL** for sale or use on pollution controlled vehicles in the state of California. These downpipes are intended for use on vehicles that are involved in closed course racing applications only. They will be referred to as "RACE USE ONLY" in any other location in this instruction sheet, or any marketing information.

The installation of downpipes onto any vehicle must be performed in accordance with all governmental regulations that pertain to the particular vehicle receiving the downpipes. Please call your Doug Thorley Headers distributor if there are any questions regarding the legality of the installation.

## THY-519-DS

### OFF ROAD DOWNPIPES

#### 2016-17 TOYOTA TACOMA, 3.5L (OFF-ROAD "RACE" USE ONLY)

#### PARTS INCLUDED

Ref.	Part Number	Description	Qty
1)		Driver Side Downpipe Assembly	1
2)		Passenger Side Downpipe Assembly	1
3)	01-5310125035-27	M10-1.25 X 35MM Flange Bolts	4
4)	01-7410125	M10-1.25 Flange Nut	4

#### TOOLS REQUIRED

##### Ref. Description

- 1) 3/8" Drive Ratchet and Extensions
- 2) 7/8" Box wrench or O2 Sensor Socket
- 3) 10mm, 12mm, 14mm Sockets

##### Ref. Description

- 5) 10mm, 12mm, 14mm Wrenches
- 6) WD40 or equivalent

#### WARRANTY NOTES

- 1) The utmost care is taken at Doug Thorley Headers ("DTH") to maintain the highest standards of quality. However, DTH cannot control the installation of the product. For this reason the warranty covers only the replacement of the components, it does not cover labor for the installation.
- 2) The use of any type of "header wrapping" immediately voids the warranty. Using any sort of wrapping material on the headers destroys the tubing's ability to dissipate heat, causing very rapid deterioration of the composition of the metal and the subsequent failure of the headers.
- 3) Any chrome plating applied to DTH header components is a high-nickel chrome finish applied to retard corrosion. This is a commercial quality "heat" chrome designed to protect the metal from the environment only. This finish is not "show chrome" and is not intended for the sake of appearance. This high-nickel chrome will turn colors and approach black as it cooks into the metal. The initial brilliance of the chrome finish is not covered under the warranty. Contamination of the surface by foreign substances may produce other color patterns. This can be prevented by routine cleaning.
- 4) Retain all paperwork pertaining to the purchase of your DTH product. Save your receipt!  
**Your limited warranty is not valid without a receipt of purchase.**

**THY-519-DS-C**

**OFF ROAD DOWNPIPES**

**2016-17 TOYOTA TACOMA, 3.5L  
(OFF-ROAD "RACE" USE ONLY)**

## **INSTALLATION NOTES**

**Installation of these downpipes will trigger a CEL (check engine light). This minor problem can be corrected with either a performance tune or tuner, and/or an o2 sensor simulator offered by many companies in the aftermarket.**

- 1) It is important that you read the entire instruction sheet before beginning any installation.
- 2) Due to restricted room in the engine compartment your downpipes may come close to certain body and chassis components, this is normal for an installation of this type. However, a careful inspection must be completed to ensure that the distances and placement are reasonable and logical, especially with regard to electrical, fuel, and brake components.
- 3) Because of car-to-car variations, DTH strongly recommends that these downpipes be installed by an experienced installation shop that has welding and fabrication capabilities.

## **INSTALLATION PROCEDURE**

### **OE MANIFOLD REMOVAL**

- 1) Disconnect battery terminals.
- 2) Coat all hardware down with WD-40 or equivalent.
- 3) Disconnect the oxygen sensor wiring from the vehicle's wiring harness at the connector, and remove the wiring from any retention clips that may be present. Remove the oxygen sensor.  
*NOTE: Failure to disconnect the oxygen sensor wiring so that it is free to rotate with the oxygen sensor can seriously damage the oxygen sensor.*
- 4) Remove the four bolts connecting the downpipes to the exhaust system.
- 5) Remove the two bolts connecting the downpipes to the support brackets attached to the transmission.
- 6) Remove the four bolts attaching the support brackets to the transmission. You must reuse these support brackets with your new downpipes to prevent fatigue and possible breakage of the new downpipes.
- 7) Remove the 8 bolts attaching the factory downpipes to the cylinder heads.

**THY-519-DS-C**

**OFF ROAD DOWNPIPES**

**2016-17 TOYOTA TACOMA, 3.5L  
(OFF-ROAD "RACE" USE ONLY)**

## **INSTALLATION PROCEDURE**

- 8) Clean surface of the cylinder heads.
- 9) Work both downpipes in from the bottom.
- 10) Start all hardware but leave loose at this time.
- 11) Reinstall both support brackets and leave the hardware loose.
- 12) Starting at the bottom, begin to tighten all the hardware.
- 13) Tighten the 8 bolts joining the downpipes to the heads.
- 14) Reinstall the O2 sensors.
- 15) Reconnect the battery.
- 16) Check for clearances around the downpipes and start engine and check for leaks.
- 17) Retighten all hardware after approximately 20 minutes of run time.