

## **Application Instructions**

- 1.1. Wash car with Dr. Beasley's Matte Body Wash to remove any loose debris. Dry with microfiber towel.
- 2.2. Spray AdvanceCoat: Matte on a panel.
- 3.3. Using a clean microfiber towel, lightly buff surface. Avoid using pressure.
- 4.4. Repeat steps 2 and 3 for each coated panel.

## Dr. Beasley's Suggests:

Do not apply to a vehicle that is not coated with Dr. Beasley's Matte Paint Coating or Matte Paint Coating Pro.

Test for compatibility by applying a small amount to an inconspicuous area.