

1	Qty. (4)	Bolt M10 x 1.25 x 40mm CL8.8	2	Qty. (4)	Conical Washer
---	----------	------------------------------	---	----------	----------------

1. Remove appearance panel which covers the trunk pan. Using a small Philips tip screwdriver, unscrew plastic screws (10) while applying pressure to the opposite end, M6 nuts (3). Return plastic fascia covering to vehicle owner.

2. Lower vehicle exhaust by removing rubber exhaust hanger.

- 3. Lift hitch into position, drivers side first. Place crosstube over top of tail pipe, with the side bracket as far into space behind wheel well, rotate into position on the outside of the frame rail.
- 4. Raise the passenger side of the hitch into position on the outside of the frame rails and in front of bulkhead.
- 5. Install fasteners as shown. Hand tighten fasteners.
- 6. Push hitch toward the rear of the vehicle and tighten all fasteners.
- 7. Reattach rubber muffler hanger.

Tighten all M10 CL 8.8 fasteners with torque wrench to 42 Lb.-Ft. (57 N\*M)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.

Looking for dependable trailer hitches and towing? Rely on Draw-Tite for quality and long-lasting products.