

Weight Carrying

Ball Mount

2000 lb. (908 Kg)

200 lb. (91 Kg)

Drawbar Kit: **Hitch Shown In Proper Position** Wiring Access Location: (Sebring) PC3 & PC4 3594 **Equipment Required:** Drawbar must be used in the Wiring Access Location: (Avenger) PC1 & PC2 Rise position only. Wiring Access Location: (200) PC1 & PC2 Fastener Kit: 24871F Wrenches: 3/4", 7/8" Drill Bits: None Spray lubricant Fish wire Vehicle frame Vehicle frame Vehicle forward 8

	Qty. (2)	1/2"-13 X 4-1/2" Gr.5 Hex Bolts	4	Qty. (4)	1/2" Hex nuts
2	Qty. (2)	1/4" X 1-1/2" X 3" Blocks	5	Qty. (2)	1/4" X 1" X 2" Blocks
3	Qty. (4)	1/2" Conical washers	6	Qty. (2)	1/2"-13 X 1-3/4" Gr.5 Carriage Bolts

- Remove exhaust hangers both sides. Spraying a lubricant on the metal hanger rod and the rubber isolator helps removal. 1.
- Raise hitch into position and insert 4-1/2" bolts and blocks through frame and hitch both sides. Install conical washers and 1/2" 2. nuts. Hand tighten only.
- Use Fishwire (provide) to install Carriage bolt and block through square hole forward on frame. Keep bolt and block separate until inside of frame. Install conical washers and 1/2" nuts. Hand tighten only. 3.
- 4. Tighten all (4) 1/2" fasteners installed in Step 2 and 3.

Tighten all 1/2" hex bolts with torque wrench to 40 Lb.-Ft.

Tighten all 1/2" carriage bolts with torque wrench to 75 Lb.-Ft.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.