

Installation Instructions

Part Numbers:


HYUNDAI TUCSON

36510

KIA SPORTAGE

90211

06132



Drawbar Kit:
36001



**Do Not Exceed Lower of Towing Vehicle
Manufacturer's Rating or**

3500 Lb. (1589 kg) Max Gross Trailer Weight

300 Lb. (136 kg) Max Tongue Weight

Hitch Shown In Proper Position

Equipment Required:


Fastener Kit: 36510F

Wrenches: 16mm

Drill Bits: NONE

Wiring Access Location: SUV1, SUV2 (Tucson)

SUV1, SUV5 (Sportage)



①	Qty. (4)	Hex Bolt – M10 x 1.25 x 30mm CL 10.9	②	Qty. (4)	Conical Washer – 3/8"
---	----------	--------------------------------------	---	----------	-----------------------

1. Raise vehicle with hoist or ramps for access to underside.
2. While supporting exhaust remove rear hangers and lower exhaust until hitch can be positioned over the muffler tips and into position aligning slots in hitch with existing weld nuts in the bottom of frame.
3. Loosely install the M10 hex bolts with conical washers, (4) four places, as shown.
4. Tighten all M10 CL10.9 fasteners with torque wrench.
5. Reinstall rear hangers for exhaust.

Tighten all M10 CL 10.9 fasteners with torque wrench to 42 Lb.-Ft. (57 n*m)

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.