

- 1. Lower exhaust as follows:
  - On driver's side, disconnect rubber exhaust hanger forward of muffler. (Lubricating Spray Recommended) On passenger's side, remove exhaust hanger bracket by removing (2) M8 fasteners. Discard M8 fasteners.
- 2. On driver's side, bend or cut heat shield to expose hole in frame rail.
- 3. Fishwire carriage bolts and spacer blocks up thru access holes in each frame rail and down thru attaching holes as shown above. See figure 3.
  - Note: On both sides, at access hole in vehicle frame, refer to figure 2 to reverse fishwire block and bolt up thru large slot and back down thru same slot.
- 4. On driver's side, remove existing M12 bolt at forward most attachment and retain for hitch installation (Do not clean threads).
- 5. Raise hitch into position, being careful not to push bolts back into frame. Loosely attach with conical toothed washers and nuts.
- 6. Align holes in hitch with holes in vehicle. Install remaining fasteners as shown above and tighten.

Tighten all M8 x 1.25 CL9.8 fasteners with torque wrench to 20 Lb.-Ft. (27 N\*M)

Tighten all ½-13 GR5 fasteners with torque wrench to 75 Lb.-Ft. (102 N\*M)

Tighten all M12 x 1.50 CL10.9 fasteners with torque wrench to 92 Lb. Ft. (125 N\*M)