

If present, remove the tie down brackets from vehicle frame rail. Return bolts and tie down bracket to owner.

- 1. Raise hitch into position and install fasteners as shown above.
- 2. Tighten all fasteners with torque wrench to 68 Lb.-Ft. (92 N*M)

Cequent



Tighten all M12 CL8.8 fasteners with torque wrench to 68 Lb.-Ft. (92 N*M)