Part Numbers: **Installation Instructions** 36523 Subaru Forester 90228 06155 Do Not Exceed Lower of Towing Vehicle Manufacturer's Rating or Fascia Max Gross Max Tongue Hitch type Trailer WT (LB) WT (LB) Weight Carrying 3500 (1589 Kg) 300 (136 Kg) **Hitch Shown In Proper Position** Ball Mount Drawbar Kit: 36053 В Wiring Access Location: SUV8 Accessory Rating **Equipment Required: Metal File** Fastener Kit: 36523F 1.125 (28.58mm).563 Wrenches: 3/4", 10mm (14.30mm)Drill Bits: 3/8" Fasteners Typical Both Sides Existing 3/4" Diameter hole in frame 3/8" Dia. Drilled holes Figure 2: Access hole modification to allow Fishwiring of block and carriage bolt. Figure 3: Kink pull wire to keep Spacer independent of bolt A. Insert bolt and Figure 1 B. Align block on C. Pull bolt thru Block into frame access hole block Figure 4: Fishwiring Procedure 1 Qty. (6) Carriage Bolt - 1/2-13 x 1.75 GR5 4 Qty. (6) Hex Nut - 1/2-13 Spacer- $\frac{1}{4}$ x 1 x 3 (Square hole for $\frac{1}{2}$ " Carriage Bolt)

- Lower exhaust by disconnecting rubber exhaust hanger(s) from hanger bracket(s). 1.
- 2. Remove (4) heat shield screws from the frame rail and set aside.
 - Note: When hitch is installed, heat shield will need to be discarded or trimmed to fit in position.
- Remove (3) plastic plugs from existing holes in each frame rail and discard. 3.
- Use 3/8" drill and file to modify center hole in each frame rail, as shown in Figure 2, to allow fishwiring of spacers and carriage bolts. 4.
- 5. Fishwire spacers and 1/2" carriage bolts thru access hole modified in Step 4 and down thru holes in both frame rails (see figure 3), making sure blocks span both sides of hole (see Figure 4) and are not overlapping one another.

(5)

Qty. (6)

Pull Wire - 1/2"

- Raise hitch into position, being careful not to push fasteners into frame, and secure with conical washers and nuts. 6.
- 7. Reinstall heat shield and fasteners removed in Step 2.

Conical Washer - 1/2"

8. Raise exhaust back into position and reinstall exhaust hangers disconnected in Step 1.

Cequent

2

3

Qty. (6)

Qty. (6)



Tighten ½-13 GR5 fasteners to 75 lb.-ft. (102 N*M)