


Front Mounted Receiver Installation Instructions

Part Numbers:

65031

**Toyota Tundra
Toyota Sequoia**



**CARGO CAPACITY – DO NOT EXCEED
500 LB. OR VEHICLE FRONT GROSS
AXLE WEIGHT RATING. (GAWR)**

9000 LB. MAX. WINCH LINE PULL

Receiver Shown In Proper Position


Hitch Requires 5/8" Pin and Clip

Equipment Required:

Fastener Kit: F65031

Wrenches: 3/4", 18mm, 19mm

Drill Bits: 1/2"



①	Qty. (2)	Hex Bolt, 1/2"-13 x 1-3/4"	④	Qty. (2)	Handle Nut, 1/2"
②	Qty. (2)	Lock Washer, 1/2"	⑤	Qty. (4)	Hex Bolt, M12 x 1.25 x 35
③	Qty. (2)	Flat Washer, 1/2"	⑥	Qty. (4)	Conical Washer, 1/2"

1. Remove skid plates and tow hooks from vehicle and return to customer.
2. Raise receiver into position and install four (4) M12 bolts.
3. Using receiver as a template, drill two (2) holes in frame.
4. Insert handle nuts thru access holes in frame and install two (2) 1/2"-13 bolts as shown.

Cequent



Tighten all M12 CL8.8 fasteners with torque wrench to 68 Lb.-Ft (92 N-m).

Tighten all 1/2" GR5 fasteners with torque wrench to 50 Lb.-Ft (68 N-m).