



## Dupli-Color® BED ARMOR™

### DIY Truck Bed Liner

Dupli-Color® BED ARMOR™ DIY Truck Bed Liner is a water-based, rubberized polyurethane coating ideal for protecting truck beds, and all other metal, aluminum, fiberglass, and wood surfaces. Formulated with DuPont™, BED ARMOR™ DIY Truck Bed Liner offers superior adhesion, impact resistance, and flexibility, as well as an attractive, texturized satin black finish that provides the ultimate in truck bed protection. BED ARMOR™ DIY Truck Bed Liner is a low-odor product that can be cleaned with soap and water and does not have a working pot life. Any unused product can be resealed in its container and used later for touch-up or on other projects.

### Application Instructions

**NOTE:** The use of safety goggles and rubber gloves are recommended.

1. Remove tailgate and hinge arms or cables.
2. Clean truck bed and tail gate using a broom, stiff brush or pressure washer to remove all loose dirt and debris. Use a strong household detergent or wax and grease remover to thoroughly remove oils, chemicals or other contaminants.
3. Rinse truck bed and tailgate with fresh clean water and let dry thoroughly.
4. Mask off all hardware, drain plugs and areas of the truck bed and tailgate you do not want BED ARMOR™ to bond to.
5. Using the supplied scouring pad, scuff all areas of the truck bed and tailgate where BED ARMOR™ would be applied. Scuffing glossy surfaces will ensure a superior bond to the surface.
6. Use a broom or air hose to remove all sanding dust.
7. Wipe down truck bed and tailgate with wax and grease remover, such as Dupli-Color Prep Spray.
8. Open BED ARMOR™ and stir contents with provided stir stick. Stir contents every 10 minutes during application process.
9. Pour BED ARMOR™ into the supplied roller tray. Start coating the truck bed and tailgate using the provided 2" brush and dab BED ARMOR™ into the seams and areas where the roller will not reach. **NOTE:** A wet rag can be used to clean off any BED ARMOR™ from unwanted areas. Cleaning must be performed while BED ARMOR™ is still wet.
10. Working from front to back, use the supplied roller and roller frame to apply a light first tack coat. Let the first coat dry for at least 1 hour or more before stepping back into the truck bed for second coat.
11. Apply a second heavier coat. Repeat step 9 if needed. **NOTE:** Two coats of BED ARMOR™ are necessary for full complete coverage. Missed areas can be touched up at any time.
12. Allow BED ARMOR™ to dry for 2- hours before removing masking tape. Remember to pull masking tape AWAY from fresh coating.
13. Clean all tools using water before BED ARMOR™ has dried. Make sure the container lid is securely sealed back on to container. Unused BED ARMOR™ can be used at any time.
14. Install tailgate and all associated hardware.
15. A BED ARMOR™ protected truck bed will be ready for light-duty use in 24 hours and heavy-duty use in 48 hours.

### Usage

A BED ARMOR™ protected truck bed will be ready for light-duty use in 24 hours and heavy-duty use in 48 hours.

### Recoat

Dupli-Color® BED ARMOR™ does not have a recoat window. Additional coats or touch-up can be re-applied to BED ARMOR™ coated surfaces at anytime.

### Cleaning

**Wet:** Dupli-Color® BED ARMOR™ is a water-based polyurethane. Hands, tools, and other surfaces can be cleaned with soap and water before drying (Approximately 30 minutes).

**Dry:** Once cured, Dupli-Color® BED ARMOR™ cannot be satisfactorily removed. Properly cured surfaces can be cleaned with water and neutral commercial or household cleaners.

### Alternate Surfaces

BED ARMOR™ DIY Truck Bed Liner is ideal for use on metal truck beds. It is also ideal for use on any other wood, metal, fiberglass, or aluminum surfaces.

BED ARMOR™ DIY Truck Bed Liner can be used for many different applications: Jeep/4x4 tubs, automotive under coating, running boards, trailers, boat docks, tractor beds, tool boxes, and many more.

### Coverage

A gallon of Dupli-Color® BED ARMOR™ DIY Truck Bed Liner will cover approximately 60-70 square feet. This is enough liner to properly apply the recommended 2-coats to all standard-sized 6 foot truck beds. All extended truck beds larger than 6 feet will require the purchase of an additional quart to achieve proper coverage.

### WARNING!

#### VAPOR HARMFUL.

#### IRRITATES EYES, SKIN AND RESPIRATORY TRACT. CONTAINS DIOCTYL PHTHALATE.

**VAPOR HARMFUL.** Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area.

Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage.

**FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water for 15 minutes and get medical attention. For skin contact, wash thoroughly with soap and water. In case of respiratory difficulty, provide fresh air and call physician. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately.

#### DELAYED EFFECTS FROM LONG TERM OVEREXPOSURE.

Contains solvents which can cause permanent brain and nervous system damage. Intentional misuse by deliberately concentrating and inhaling the contents can be harmful or fatal.

Contains Dioctyl Phthalate which may cause cancer based on animal data.

**WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

#### DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.





