

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX DUAL KIT: 19389**

2004 Dodge Durango w/4.7L, 5.7L V8 Engines,
2WD/4WD



DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.


1. Remove the OE front muffler assembly and the OE rear resonator assembly. To assist in removal, it is recommended that the rubber hanger isolators be lubricated with WD-40 or a similar product.
2. Install DynoMax front pipe **41801** to the outlet of the converter/y-pipe assembly. The rod hanger should slip into the the rubber isolator located off the passenger side frame rail. Finger tighten the supplied 2 $\frac{3}{4}$ " U-Bolt clamp onto the inlet of this pipe.
3. Install DynoMax muffler **17665** onto the outlet end of pipe 41801. The outlet end of the muffler is marked with the word 'OUTLET'. The muffler body should lie flat when properly installed with the muffler inlet connection closes to the drive shaft. Finger tighten a 3" U-Bolt clamp onto the muffler inlet connection. (If equipped, attach the OE electrical grounding strap nut to one of the muffler clamp u-bolt ends when performing the final tightening sequence. See step 6.)
4. Install rear extension pipe **52225** into the outlet of the muffler. Position the two rod hangers into the proper rubber isolators above the rear of the muffler. The two rod hangers should point toward the rear of the vehicle when properly installed. Finger tighten a 3" U-Bolt clamp onto the muffler outlet connection to this pipe.

5. Install tail pipe **55211** onto the outlet of pipe 52225. Slide the tail pipe rod hanger into the two rubber isolators at the rear of vehicle.
6. Beginning from the inlet end, position all components and tighten clamps. Please see full system diagram on the back page.

KIT CONTAINS:

- (1) 17665 MUFFLER
- (1) 41801 PIPE
- (1) 52225 PIPE
- (1) 55211 PIPE
- (1) 2 $\frac{3}{4}$ " CLAMP
- (3) 3" CLAMPS
- (1) INSTRUCTION SHEET

19389 SYSTEM DIAGRAM



Look through our comprehensive collection of performance exhaust systems right away.