

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19413**

2004-05 Dodge Ram 5.7L , All Models, 2/4 W.D.
(Including the Rumble Bee edition)
Single Exhaust System



DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.


1. Remove the original muffler and tail pipe, only, from the vehicle. If installing this system on a reg. cab, long bed, or any quad cab model, do **NOT** remove the original inlet extension pipe from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax muffler inlet pipe **41975**. Finger tighten the inlet 2 $\frac{3}{4}$ " clamp. (Please note: If installing this system on a Rumble Bee edition, cut 1" off the outlet end of 41975. This will insure that the tail pipe tip will exit through the right side body cladding cut-out properly.
3. Install DynoMax Ultra Flo Welded Muffler **17233** with the side connection as the inlet. The muffler should be installed at approximately a 45° angle with the top tilting toward the driveshaft. Also install clamp-on hanger **36257** at the muffler to inlet pipe connection. Insert the rod hanger into the rubber isolator hanging from the R.H. frame. Finger tighten the clamps connections.
4. Install DynoMax tail pipe **55118**. Insert the metal rod hangers into the rubber isolators on the chassis. Finger tighten the 3" inlet clamp.

5. Install spout **36474** onto the outlet end of the tail pipe. Use the **33272** band clamp to connect the tip to the tail pipe. Install the band clamp with the fasteners on top.
6. Beginning at the inlet end, align all the parts and fully tighten all clamps.
7. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17233 MUFFLER
- (1) 41975 INLET PIPE
- (1) 55118 TAIL PIPE
- (1) 36474 SS SPOUT
- (1) 36257 HANGER
- (1) 2 $\frac{3}{4}$ " U-BOLT CLAMP
- (1) 3" U-BOLT CLAMP
- (1) 3" BAND CLAMP
- (1) INSTRUCTION SHEET

19413 SYSTEM DIAGRAM



Look through our comprehensive collection of performance exhaust systems right away.