

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39432**

2010-07 Chevrolet Silverado / GMC Sierra 2500HD, 3500 6.0L,
All Models, 2 / 4 W.D., Single Exhaust



DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the original equipment (OE) inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front exhaust pipe 52462. Finger tighten the nuts on the inlet flange studs
3. If installing this system on a reg. cab/long bed (133" W.B.) go to step 4. If installing on any other cab type, please follow these directions. Install extension pipe **53734** after completing the following cut-off on the outlet OD sized end. For an ext. cab/short bed (143.5") cut off 24". For a crew cab/short bed (153") cut off 14". For an ext. cab/long bed (157.5") cut off 9.5". For a crew cab/long bed (167") no cut off is required on 53734
4. Install DynoMax Ultra Flow Welded muffler 17557 with long dimension of the oval muffler in a vertical position and the inlet end connection at the bottom. See the system diagram on the back page.
5. If your truck is a reg. cab/long bed (133"), an ext. cab/long bed (157.5") or a crew cab/long bed (167") install clamp-on hanger **36410** at the connection of the muffler inlet to the front exhaust pipe or extension pipe. Insert the rod into the rubber isolator on the RH frame. See the system diagram on the back page. If your truck is an ext. cab/short bed (143.5") or a crew cab/short bed (153") install clamp-on rod hanger **36409** instead of and in place of the 36410.
6. Also install clamp-on rod hanger **36408** onto pipe 53734 if your truck is a crew cab/short bed (153"), an ext. cab/long bed (157.5") or a crew cab/long bed (167"). See the system diagram on the back page.

7. Install DynoMax tail pipe **55547**. Insert the metal rod hangers into the two rubber isolators on the chassis. Finger tighten the 4" clamp to the muffler outlet.
8. Install the stainless steel spout **36477** using the band clamp provided. Install the band clamp with the fasteners on top.
9. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
- 10 Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17557 MUFFLER
- (1) 52462 INLET PIPE
- (1) 53734 EXTENSION. PIPE
- (1) 55547 TAIL PIPE
- (1) 36477 SPOUT
- (1) 36408 CLAMP-ON HANGER
- (1) 36409 CLAMP-ON HANGER
- (1) 36410 CLAMP-ON HANGER
- (3) 4" BAND CLAMPS
- (1) 710610 INSTRUCTION SHEET

Cab Type — Wheel Base

- Reg. Cab, Long Bed — 133"
- Ext. Cab, Short Bed — 143.5"
- Crew Cab, Short Bed — 153"
- Ext. Cab, Long Bed — 157.5"
- Crew Cab, Long Bed — 167"

39432 SYSTEM DIAGRAM

