

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39442**

2008-07 Chevrolet Suburban 1500 (1/2 Ton) /
GMC Yukon XL 1500 (1/2 Ton) 5.3L V8



DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front exhaust pipe 54846. Insert the metal rod hanger into the rubber isolator on the chassis. Finger tighten the nuts on the inlet flange.
3. Install DynoMax Ultra Flo Welded muffler **17235**. The muffler should lie flat and install with the center connection as the inlet with the side outlet connection toward the passenger side. Lightly tighten the 3" inlet clamp at the connection to the front pipe.

4. Install DynoMax tail pipe **55607**. Insert the three (3) metal rod hangers into the rubber isolators on the chassis. Lightly tighten the 3" clamp to the muffler outlet.
5. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
6. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 54846 Inlet Pipe
- (1) 17235 Muffler
- (1) 55607 Tail Pipe
- (2) 33272 3" Clamp
- (1) Instruction Sheet

39442 SYSTEM DIAGRAM

