

**INSTALLATION INSTRUCTIONS FOR  
DYNOMAX MUFFLER KIT: 39522**  
2014-12 Jeep Wrangler Unlimited 3.6L



**DANGER WARNING:** SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME. BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

**NOTE:** Please read all instructions before beginning the installation.

1. Remove the O.E. exhaust from behind the catalytic converters. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax intermediate pipe **52514**. Insert the rod hanger into the rubber isolator.
3. Install DynoMax muffler **17263**. Use band clamp **33226** at the muffler inlet & outlet connections.
4. Install mounting bracket **36517** using two existing bolts in the cross member just past the outlet location of the DynoMax muffler. Reuse one of the O.E. rubber isolators from the back of the vehicle.

5. Install DynoMax tail pipe **51084**. Be sure to insert the metal rod hanger into the rubber isolator. See system diagram on the back page of these instructions.
6. Beginning at the inlet end, align system components and fully tighten all clamps.

**KIT CONTAINS:**

- (1) 17263 MUFFLER
- (1) 52514 INTERMEDIATE PIPE
- (1) 51084 TAIL PIPE
- (1) 36517 BRACKET
- (1) 36438 BAND CLAMP
- (2) 33226 BAND CLAMPS
- (1) 713025 INSTRUCTION SHEET

# 39522 SYSTEM DIAGRAM

