



E3 DiamondFIRE Installation Instructions - Ignition Coils - E3.614

Congratulations on your purchase of an E3 DiamondFIRE Chrysler HEMI Ignition Coils. When properly installed, these Ignition Coils will give you years of trouble-free performance. These instructions are designed to assist you in installing your new E3 Ignition Coils. ***Please read these instructions in their entirety before beginning your installation***

One (1) Ultra High-Output HEMI Ignition Coil –
2006-2017 Chrysler 5.7L, 6.1L, 6.4L HEMI Coil-On-Plug

WARNING: During any electrical system installation, always disconnect both battery cables, removing the negative cable first. When you are done, reconnect the battery installing the positive lead first.



Installation

Step 1: Remove the factory coil harness from the coil. Be cautious to not damage the harness plug during this step.

Step 2: Unbolt and remove the old coil from the mount. Replace the old coil with the new E3 Ignition Coil using the factory hardware. Ensure the spark plug boots are properly seated on the spark plugs.

Step 3: Reconnect the coil harness. Ensure the connector is properly engaged in the coil.