



Installation Instructions

Dust Cover

Models A6050DC & A6070DC

Dust Cover Model A6050DC is made to use for ECCO strobe models 2550, 6520, 6524, 6550 & 6650. Model A6070DC is for use on models 2570, 6530, 6534, 6570, 6670 & 6690.

The ECCO [Dust Covers](#) are designed to be easily installed, and protect the lens optics on ECCO Strobe lights. The Dust Covers prevent dirt/dust from accumulating on the lens optics, keeping the light output to a maximum, and making the lights easy to clean. To install:

1. Make sure that the strobe lens is clean prior to installing the dust cover.
2. On “J-Bolt” model strobes (models 6520, 6524, 6530 & 6534) remove the rubber lens flange cover.
3. Place the dust cover over the lens, and press on firmly. It may be necessary to tap on the dust cover, until it clicks onto the lens. When properly installed, the dust cover will be “locked” onto the lens.



Electronic Controls Co.
An Employee Owned Company